

BATTERY OPERATED PRODUCTS

Battery Care:

To prevent battery leakage:

- Be sure to insert batteries correctly and always follow the product and battery manufacturers' instructions.
- Never mix old and new batteries (replace all batteries at the same time).
- Never mix Alkaline, Lithium, standard (Carbon Zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Always remove exhausted or dead batteries from the product.
- Remove batteries from product before extended storage.
- Do not short circuit the battery terminals.
- Batteries are to be inserted with correct polarity.
- Do not dispose of batteries in a fire, batteries may explode or leak.
- Do not allow water to come into contact with the batteries.
- Batteries may explode or leak if misused.
- Batteries should be installed by an adult only.
- Batteries should be removed from the item before disposal.

If this product can be operated using mains or via USB, ensure all batteries are completely removed before plugging in the mains or USB cable.

For products using button cell batteries:

- **Warning:** Hazardous if swallowed. Button cell batteries can cause serious internal chemical burns if swallowed. Dispose of used batteries immediately. Keep new and used batteries away from children. If you think batteries might have been swallowed or place inside any part of the body, seek immediate medical attention.

Rechargeable batteries:

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged (if removable).
- Rechargeable batteries are only to be charged under adult supervision (if removable).

Waste Electrical Products:

- The WEEE symbol indicates that this item contains electronic components which must be collected and disposed of separately.
- Never dispose of electrical waste in general municipal waste. Collect and dispose of such waste separately.
- Make use of the return and collection systems available to you, or your local recycling programme. Contact your local authority or place of purchase to find out what schemes are available.
- Electrical and electronic equipment contains hazardous substances which, when disposed of incorrectly, may leak into the ground. This can contribute to soil and water pollution which is hazardous to human health, and endangers wildlife.
- It is essential that consumers look to re-use or recycle electrical or electronic waste to avoid it going to landfill sites or incineration without treatment.



Retain leaflet as it contains important information.
For replacement parts visit our website: www.sparebulbsuk.com
PREMIER DECORATIONS LTD . United Kingdom: HA4 0EJ
EU: Inniscarra Co Dublin. D24 EO29