



flex kit

MORE INFO | ULTERIORI INFORMAZIONI | PLUS D'INFORMATIONS | MEHR INFO |
MÁS INFORMACIÓN | MEER INFORMATIE | WIĘCEJ INFORMACJI | БІЛЬШЕ
ІНФОРМАЦІЇ | ДОПОЛНИТЕЛЬНАЯ ИНФОРМАЦИЯ | VEĀ INFORMACIJA | ΤΟΥΆΒΒΙ
INFORMACIÓJ | MERE INFO | VÍCE INFORMACÍ | VIAC INFORMACIÍ | NÁNARI
UPPLÝSINGAR

 www.twinkly.com/support

INSTRUCTIONS GUIDE | GUIDA ALLE ISTRUZIONI | GUIDE D'INSTRUCTIONS |
BETRIEBSANLEITUNG | GUÍA DE INSTRUCCIONES | HANDLEIDING | INSTRUKCJA
OBŚLUGI | РУКОВОДСТВО ПО ЭКСПЛУАТАЦИИ | NAVODILA ZA UPORABO |
KEZELÉSI UTASÍTÁS | INSTRUKTIONSVEJLEDNING | NÁVOD K POUŽITÍ | NÁVOD NA
POUŽITIE | LEIÐBEININGAR

LEDWORKS SRL
Via Tortona, 37 - 20144
Milano - Italy

EN

This pack contains a set of 15 straight clips (A), 15 wood screws (B), and 15 strips of premium 3M double-sided tape (C), to be used to fix Twinkly Flex onto suitable domestic surfaces. The pack also contains 15 pieces of reusable Nano Tape (D), which can be used to fix Twinkly Flex onto a wall without leaving any marks.

wood surface

For having the best result on a wood surface a clip (A) in combination with a screw (B) is recommended.

concrete surface

For concrete it is suggested to use a double sided tape (C) in combination with the clip (A).

glass surface

In case of glass surfaces, the clip is not needed, a reusable Nano Tape (D) is provided in order to attach the Flex directly onto the surface.

IT

This pack contains a set of 15 straight clips (A), 15 wood screws (B), and 15 strips of premium 3M double-sided tape (C), to be used to fix Twinkly Flex onto suitable domestic surfaces. The pack also contains 15 pieces of reusable Nano Tape (D), which can be used to fix Twinkly Flex onto a wall without leaving any marks.

wood surface

For having the best result on a wood surface a clip (A) in combination with a screw (B) is recommended.

concrete surface

For concrete it is suggested to use a double sided tape (C) in combination with the clip (A).

glass surface

In case of glass surfaces, the clip is not needed, a reusable Nano Tape (D) is provided in order to attach the Flex directly onto the surface.

FR

This pack contains a set of 15 straight clips (A), 15 wood screws (B), and 15 strips of premium 3M double-sided tape (C), to be used to fix Twinkly Flex onto suitable domestic surfaces. The pack also contains 15 pieces of reusable Nano Tape (D), which can be used to fix Twinkly Flex onto a wall without leaving any marks.

wood surface

For having the best result on a wood surface a clip (A) in combination with a screw (B) is recommended.

concrete surface

For concrete it is suggested to use a double sided tape (C) in combination with the clip (A).

glass surface

In case of glass surfaces, the clip is not needed, a reusable Nano Tape (D) is provided in order to attach the Flex directly onto the surface.



